




**RNAV STANDARD  
DEPARTURE CHART-  
INSTRUMENT (SID) - ICAO**

KARLOVY VARY APPROACH / RADAR	118.650
KARLOVY VARY TOWER	119.955
KARLOVY VARY ATIS	121.230
EMERGENCY FREQ	118.955
	121.500



**KARLOVY VARY  
RWY 29**

BEARINGS, TRACKS AND  
RADIALS ARE MAGNETIC  
ALTITUDES AND ELEVATIONS  
ARE IN FEET  
DISTANCES ARE IN NMI



Change: SUPPLEMENTARY FREQ TWR withdrawn

TRANSITION ALTITUDE  
5000

VAR 3°E 2013