



**RNAV STANDARD
DEPARTURE CHART-
INSTRUMENT (SID) - ICAO**

KARLOVY VARY APPROACH / RADAR	118.650
KARLOVY VARY TOWER	119.955
KARLOVY VARY ATIS	121.230
EMERGENCY FREQ	118.955
	121.500



**KARLOVY VARY
RWY 29**



BEARINGS, TRACKS AND RADIALS ARE MAGNETIC ALTITUDES AND ELEVATIONS ARE IN FEET DISTANCES ARE IN NMI

SID segments outside TMA Karlovy Vary cross through airspace "Class E" below FL 95
TRANSITION ALTITUDE 5000

Close in obstacle, 50122.1N 01253.48E see AD 2.22.2.3.1.

Changes: vertical limit of CTR KARLOVY VARY and TMA II KARLOVY VARY, new TMA III KARLOVY VARY and LKD14

VAR 3°E 2013

