



RNAV STANDARD DEPARTURE CHART- INSTRUMENT (SID) - ICAO

KARLOVY VARY APPROACH / RADAR	118.650
KARLOVY VARY TOWER	119.955
SUPPLEMENTARY FREQ TWR	122.905
KARLOVY VARY ATIS	118.955
EMERGENCY FREQ	121.500



KARLOVY VARY RWY 29



BEARINGS, TRACKS AND RADIALS ARE MAGNETIC ALTITUDES AND ELEVATIONS ARE IN FEET DISTANCES ARE IN NMI


SID segments outside TMA Karlovy Vary cross through airspace "Class E" below FL 95

Close in obstacle, 501221N 0125348E see AD 2.22.2.3.1.

KV296 pass at 2900 or above

TRANSITION ALTITUDE 5000

VAR 3° E 2013



Changes: vertical limits of LKTSAA4: 4A, 4B, 4C, 4D