



**RNAV STANDARD ARRIVAL CHART - INSTRUMENT
(STAR) - ICAO**

**KARLOVY VARY
RNAV STAR RWY 29**



KARLOVY VARY APPROACH / RADAR	118.650
KARLOVY VARY TOWER	119.955
SUPPLEMENTARY FREQ TWR	121.230
KARLOVY VARY ATIS	122.905
EMERGENCY FREQ	118.955
	121.500



TRANSITION ALTITUDE
5000

BEARINGS, TRACKS AND
RADIALS ARE MAGNETIC
ALTITUDES AND ELEVATIONS
ARE IN FEET
DISTANCES ARE IN NM

