


RNAV STANDARD DEPARTURE CHART INSTRUMENT

OSTRAVA/MOŠNOV

(SID) - ICAO

RNAV SID RWY 04




SID segments outside TMA Ostrava cross through airspace "Class E" below FL 95

Pilots who require provision of ATC service in Poland shall climb so to pass BAVOK / REGLI / NETIR at FL100 or above due to airspace "Class G" up to FL 95. If unable, advise ATC and expect vectors.

OSTRAVA APPROACH / RADAR	119.375
MOŠNOV DELIVERY	124.050
MOŠNOV TOWER	118.700
MOŠNOV ATIS	120.805
EMERGENCY FREQ	118.055
	121.500

MSA
VOR/DME OTA



BEARINGS, TRACKS AND RADIALS ARE MAGNETIC
ALTITUDES AND ELEVATIONS ARE IN FEET
DISTANCES ARE IN NM

TRANSITION ALTITUDE
5000