


**RNAV STANDARD
DEPARTURE CHART
INSTRUMENT (SID) - ICAO**

BRNO APPROACH / RADAR	127.350
KUNOVICE TOWER	120.555
EMERGENCY FREQ	121.500

MSA NDB KNE




**KUNOVICE
RWY 02C**

BEARINGS, TRACKS AND
RADIALS ARE MAGNETIC
ALTITUDES AND ELEVATIONS
ARE IN FEET
DISTANCES ARE IN NM

TRANSITION ALTITUDE
5000

Departure routes may cross through airspace class E.
Check lower limits of TMA BRNO

HLV
HOLEŠOV
NDB 448
HLV
491922.27N
0173142.23E



change: lateral limits of LK TSA 2A, 2B, 2C, vertical limits of CTR TUŘANY and TMA I BRNO

